

Easy HoseGuard® finder		Nl/min - bar
1		Determine the operating pressure at the place where the later use of the HoseGuard® is planned.
2		Measure the air consumption of the consumer at operating pressure.
3		Add a safety allowance of 20% to the air consumption of the consumer!
4		Determine the intersection point of the operating pressure and air consumption in the table (see back).
5		The first curve on the right of the intersection point is our HoseGuard®. In our example the green curve = 1/4" High Flow.
6		Install the defined HoseGuard® and test the function of the tool; then perform a function test in accordance with the operating instructions.
<p>Important</p> <ul style="list-style-type: none"> The interior tube cross-sections in front of the HoseGuard® must be larger than or equal to the interior diameter of the HoseGuard®. (The HoseGuard® nominal widths are for 1/4" = 6 mm, 3/8" = 10 mm, 1/2" = 12 mm, 3/4" = 19 mm, 1" = 25 mm). The following figures must be observed as the minimum interior hose diameter: 1/4" = 6 mm, 3/8" = 10 mm, 1/2" = 13 mm, 3/4" = 16 mm / 1" = 19 mm. Extremely long hoses may cause a high pressure drop at the end of the hose. This must be accounted for during planning. Please consider that we need sufficient flow to enable the HoseGuard® to close! 		

Closing point tables
HoseGuard®
1/4"
3/8"
1/2"
3/4"
1"

